




MANUAL DE PARTES HUMIDIFICADOR DnB TIPO H



H HUMIDIFIER PARTS LIST

Part No.	Name	Part No.	Name
39887	Fan	* 5670	Strainer
H-38	Grid Ring	25,429	Flat Washer
H-336	Disc	27,139	Valve
15	Drip Cup Washer	27,249	Sling Off Washer
50-A	Double Union Washer	27,280	Inner Feed Pipe Assembly
50-L	Double Union Locknut	27286	Motor Assembly Speedy Voltage
88	Motor Shim Washer	37,384	Stand
102	Fan Guard	37,389	Case
118	Drip Pan Strainer	37,401	Drip Pan
157	Flexible Conduit	37,403	Front Head
4435	Hex Nut	37,404	Back Head
4441	Hex Nut	* 37,406	Bracket
5001	Cap Screw	* 37,407	Single Union
5008	Cap Screw	* 37,429	Outer Feed Pipe
5043	Cap Screw	37,430	Orifice Housing Piping Assembly
5157	Cap Screw		
5171	Cap Screw		
5307	Set Screw		
5501	Cap Screw		

* component parts in orifice housing piping assembly 37409